# NEK Duct Electric Heaters

**CONSTRUCTION** The electric heater is provided with electric heaters with ribbed bars which operate at low temperature. The heaters are encased in galvanized sheet housing and are connected in heating sections. **INSTALLATION** It is recommended to install the heater downstream the fan. In case of necessity of installing the heater upstream the fan, air temperature should not exceed 40oC. **REMARK** The heaters should not operate at air speed lower than 2,5 m/s. Pressure drop is given for inflow speed.

JUWENT
31 Lubelska str., 08-500 Ryki
+48 502 087 841, +48 664 465 243
export@juwent.com.pl