

TR speed controller

TR Speed Controller is used for stepless speed control of single-phase WD-16-J, WD-20-J, WD-25-J, WD-31,5-J roof fans.

JUWENT
ul. Lubelska 31, 08-500 Ryki
+48 81 883 56 00
info@juwent.com.pl

Podstawowy

Supply voltage	230V
Regulated load voltage	90...230V
Continuous load current	5A
Load power	500 W
Slow blow fuse	5 A
Power switch	2-step

JUWENT
ul. Lubelska 31, 08-500 Ryki
+48 81 883 56 00
info@juwent.com.pl